How to configure the H3 core switch



Overview

Whether you''re a network administrator or just starting out with networking, this video will provide you with the knowledge to confidently configure your H3C switch.

Key Takeaways

Configuring an H3C core switch involves setting up management access, VLANs, interfaces, routing, DHCP, and security features using CLI or web interface commands.

Initial Access and Management Setup

Log in to the switch using a console cable, SSH, or Telnet from a PC. Use a terminal emulation program to connect to the device. Configure a management VLAN (avoid using VLAN 1).

For example, create VLAN 5 and assign an IP address to the management interface: CodeCopysystem-viewvlan 5interface Vlan-interface 5ip address 192. 168. 1.

1 255. 255. 255.



© 2026 ENSAA OPTICAL NETWORKS - All rights reserved

0 Enable Telnet or SSH for remote management and create a local user with administrative privileges: CodeCopylocal-user admin class managepassword simple YourPasswordservice-type telnet sshsave VLAN and Interface ConfigurationCreate VLANs for different departments or network segments: CodeCopyvlan 10vlan 20 Assign ports to VLANs and configure trunk or hybrid links for uplinks: CodeCopyinterface GigabitEthernet 1/0/1port link-type accessport default vlan 10interface GigabitEthernet 1/0/24port link-type trunkport trunk permit vlan 10 20 Configure link aggregation if connecting to access switches or routers: CodeCopybridge-aggregation 1interface GigabitEthernet 1/0/23port link-aggregation group 1 Routing and DHCPConfigure VLAN interfaces with IP addresses for inter-VLAN routing: CodeCopyinterface Vlan-interface 10ip address 192.

168. 10. 1 255.

255. 255. 0interface Vlan-interface 20ip address 192.

168. 20. 1 255.

255. 255. 0 Set up a default route to the egress router: CodeCopyip route-static 0.

0. 0. 0 0.

0. 0. 0 192.

168. 100. 1 Enable DHCP server on the core switch for different VLANs: CodeCopydhcp enableip pool DeptAnetwork 192.

168. 10. 0 mask 255.

255. 255. 0gateway-list 192.

168. 10. 1ip pool DeptBnetwork 192.

168. 20. 0 mask 255.

255. 255. 0gateway-list 192.

168. 20. 1 Security FeaturesEnable DHCP snooping on access ports to prevent rogue DHCP servers: CodeCopydhcp snooping enableinterface GigabitEthernet 1/0/1dhcp snooping trust Configure IPSG (IP Source Guard) to verify source IP and MAC addresses: CodeCopyipv4 source-guard enableinterface GigabitEthernet 1/0/2ipv4 source-guard Enable STP to prevent loops and configure priorities if needed: CodeCopystp enablestp priority 4096 Saving ConfigurationAfter completing the configuration, save it to ensure persistence across reboots: CodeCopysave Additional TipsUse display vlan and display interface brief to verify VLAN and port assignments.

© 2026 ENSAA OPTICAL NETWORKS - All rights reserved

Use display ip routing-table to check routing configuration. For advanced features like 802. 1X authentication, aggregation monitoring, or hybrid port configuration, refer to the H3C CLI reference.

By following these steps, you can configure an H3C core switch for a small to medium-sized campus network, ensuring proper management, VLAN segmentation, routing, DHCP services, and security enforcement.

Article Content

Configure the core switch

Configure the core switch Related Links Create VLANs Configure VLAN interfaces Set the link type for the interfaces and assign them to VLANs Configure a DHCP address pool Configure a static route

How To Configure H3C Switch (UPDATED)

Whether you''re a network administrator or just starting out with networking, this video will provide you with the knowledge to confidently configure your H3C switch.

Basic CLI Commands on H3C Switch

Learn how to create users, VLANs, enable Telnet and SSH, configure Spanning Tree Protocol, enable DHCP snooping, define trunk ports, and create access

H3C Switch Command Mastery: Streamlined Configuration

This article provides a hands-on guide to 50+ essential H3C switch commands, revealing hidden shortcuts and best practices derived from real-world deployments in Fortune 500 ...

H3C Campus Fixed-Port Switches Web-Based Configuration Guide

The H3C Campus Fixed-Port Switches Web-Based Configuration Guide describes the web functions of the H3C Campus Fixed-Port Switches, such as web overview, task fundamentals, and configuration

HP H3C Switch Configuration Guide: Your Network''s Blueprint? Can ...

Whether you''re setting up a basic access layer for a small office or configuring complex VLANs, QoS policies, and security features for a demanding enterprise environment, this ...

How to Master H3C Device Switch Commands: A Comprehensive Guide

© 2026 ENSAA OPTICAL NETWORKS - All rights reserved

Ready to optimize your network management? Explore our comprehensive guide to H3C device switch commands. Upgrade your skills and browse Router Switch for top-notch products now.

H3C switch HTTP access configuration complete guide: from entry to ...

Below, this article will take the H3C simulator switch as an example to introduce the setting steps in detail. 1. Connecting devices. Use a console cable to connect the computer to the console

H3C S5560S-EI SERIES CONFIGURATION MANUAL Pdf Download

Configuring Ethernet interfaces The Switch Series supports Ethernet interfaces, management Ethernet interfaces, Console interfaces, and USB interfaces. For the interface types and the number of

How To Configure Your Windows Security Settings in 2026 | All About

How To Configure Your Windows Security Settings in 2026 [Step-by-Step Guide for Windows 11] Windows Security features more key settings than you might expect. Learn how to set

Use LangChain with models in Microsoft Foundry

Learn how to use OpenAI-compatible LangChain classes with chat and embedding models deployed in Microsoft Foundry, including prompt chains, async calls, and vector search.

How to choose the default GPU for games or apps in

Usually, Windows 11 automatically switches between graphics cards, depending on the apps you are using and the games you''re playing. However,

Understand and Mitigate Network Loops (STP)

Gateway switch ports do not support STP. Configure RSTP to Prioritize Core Switches: Configure Spanning Tree Protocol settings to prioritize core switches. Setting STP priorities properly ensures

How to Configure Istio for Applications

How to Configure Istio for Applications Complete guide to running ASP Core applications in an Istio service mesh with health checks, header propagation, and Kestrel configuration.

How to Configure Virtual Switches in Hyper-V (2025

Complete guide to Hyper-V virtual switches. Configure External, Internal & Private switches with step-by-step instructions.

© 2026 ENSAA OPTICAL NETWORKS - All rights reserved

How Configure Wi-Fi Network Using Starlink AppRead

How to Configure Your Wi-Fi Network Using the Starlink App (2026 Guide) By George Posted on November 20, 2024 Updated on April 14, 2026 1

AWS vs Azure vs Google Cloud: comprehensive

Compare AWS vs Azure vs Google Cloud on complexity, costs, vendor lock-in, and Kubernetes management. Technical comparison for

RivaTuner (RTSS) & MSI Afterburner Overlay Guide:

Settings to configure the overlay toggling and profile switching hotkeys, the refresh period, metric interval, and reset metrics data. The

Related Video Reference

This video was associated with the source search result. Verify technical details against current product documentation and project requirements.

Contact Us

Continue your research online:

Website: https://ensaa.es
Technical inquiry: https://ensaa.es/contact.html

This document is for preliminary research. Verify specifications against current standards, product documentation and project requirements.

© 2026 ENSAA OPTICAL NETWORKS - All rights reserved